

Opening the sample container

Quartz glass tube  
for borescope

Stage 2

Quartz glass tube  
for borescope

Stage 1

Turn upside down

Stage 3

Transfer rod 1

Transfer rod 2

Docking with CC3-1 with  
purging N<sub>2</sub> or dry air

